



**Product Code . DS-BAS-10058**

## **Floor Counting Scale 16kg**

### **Description**

---

#### **Floor Counting Scale 16kg**

##### **Description:**

Floor Counting Scale is a fully featured counting scale with numeric keypad for unit weight and sample entry. A grade 304 stainless steel top pan with mild steel base and pillar mounted ABS plastic indicator, make the GBC a durable industrial floor counting scale. The bright large backlit display shows unit weight, total weight and number of pieces.

##### **Features:**

- Date and time
- Overload protection
- Non-slip adjustable leveling feet
- Large stainless steel platform
- Pillar mounted
- Selectable multi-language text for printing

- 
- Preset counting to a value
  - Grade 304 stainless steel pan
  - Large backlit LCD display
  - Full color coded keypad with numeric entry
  - Simple user-friendly operation
  - RS-232 bi-directional interface
  - External calibration
  - Auto sleep / power down function to save battery life
  - Low battery indication
  - AC Adapter

### **Specifications:**

- Class: Floor Counting
- Capacity: 35 lb / 16 kg
- Readability: 0.001lb / 0.5g
- Repeatability (S.D.): 0.002lb / 1g
- Linearity ( $\pm$ ): 0.002lb / 1g
- Pan Size: 11.8x15.7" / 300x400mm
- Units of Measurement: Kilogram (kg), Pound (lb)
- Interface: Bi-directional RS-232
- Calibration: External mass.
- Display: LCD, backlit
- Power Supply: 12 VDC, 800 mA adapter and internal rechargeable battery
- Overall Dimensions: 11.8x20.5x26.8 inches / 300x520x680 mm.

---

Martinfield Business Centre, 108 Martinfield, Welwyn Garden City , United Kingdom

Direct Contact Details  [sales@didacscientific.co.uk](mailto:sales@didacscientific.co.uk)

 [www.didacscientific.co.uk/](http://www.didacscientific.co.uk/)