

**Product Code . DS-DASGAGM-10485**

Basic Force Gauges

Description

Basic Force Gauges

Description:-

These digital force gauges are designed for basic tension and compression force testing applications up to 100 lb (500 N). A backlit graphic LCD displays the current, peak tension, or peak compression reading. The 500 Hz sampling rate and $\pm 0.5\%$ accuracy provide accurate peak and compression measurements.

- o Three selectable units of measurement
- o 500 Hz sampling rate
- o Large, backlit graphic display with auto-dimming
- o Calculates peak tension and compression values
- o Ultra-compact, ergonomic housing
- o Configurable default measurement unit and mode
- o Reversible housing for alternate load cell orientation.

