



**Product Code . DS-DASGAGM-10498**

## **Torque and Angle Electronic Torque Wrenches**

### **Description**

---

#### **Torque and Angle Electronic Torque Wrenches**

##### **Description:-**



Specifically designed to meet the requirements where torque plus angle is required and features three units of torque — ft. lbs., in.lbs., and Nm, plus an angle mode for additional flexibility. These electronic torque and angle wrenches incorporate the latest technology into a simple-to-use digital wrench.

- o  $\pm 2\%$  accuracy CW of indicated value
- o 3-step LED visual signal system:
- o Ergonomic non-slip cushion grip
- o Low maintenance — change batteries at 80 hours
- o Yellow = approaching target torque
- o Green = target torque reached
- o Red = over torque indicator
- o 15% Flex ratchet head and push-button socket release head
- o Gyro chip senses 360° of movement, and is accurate to within  $\pm 1^\circ$

---

o Handle vibrates when target torque is reached; almost impossible to over torque.

---

Didac Scientific Pvt. Ltd,  
Martinfield Business Centre, 108 Martinfield, Welwyn Garden City , United Kingdom  
Direct Contact Details  [sales@didacscientific.co.uk](mailto:sales@didacscientific.co.uk)  
 [www.didacscientific.co.uk/](http://www.didacscientific.co.uk/)