



Product Code . DS-HT-10516

## Digital Shore Durometer

### Description

---

#### Digital Shore Durometer

##### Description:-

Portable Durometers conform to Shore scale and are just right for testing the hardness of flexible materials such as rubber and plastics.

• **Applications:** 35° blunt taper Durometers are suitable for testing soft and natural rubber products, neoprene, polyesters, soft P.V.C., leather, nitril rubbers, wax, felt and more. Sharp 30° point Durometers are ideal for testing hard rubber, hard synthetic materials, e.g. acrylics, glass, polystyrol, thermo-plastics, printing rolls, vinyl sheets, cellulose acetates, densified wood, etc.

• Durometer Bench Stand intended for use with 1 kg loading for Shore “A” scales and 5 kg loading for Shore “D” scales.

• This concept of a low physical force lifting a fixed mass is ideal for both laboratory and production applications.

• Maximum height of piece to be tested 5.12"/130 mm.