



Product Code . DS-MPA-10539

Handheld Digital Moisture-in-Oil Meter

Description

Handheld Digital Moisture-in-Oil Meter

Description:-

The meter measures water activity which directly indicates the risk of free water formation. Measurement is independent of oil type, age, and temperature. Measure moisture in oil with this rugged and reliable meter. Take a sample of your system oil and measure the moisture content — or install a ball valve and insert the probe directly through the valve for in-process checking. Backlit LCD displays water activity and temperature readings, or select the graphical display to view your results as a curve. Menu-based interface steps you through the meter functions.

Didac Scientific Pvt. Ltd,
Martinfield Business Centre, 108 Martinfield, Welwyn Garden City , United Kingdom
Direct Contact Details ✉ sales@didacscientific.co.uk
💻 www.didacscientific.co.uk/