



**Product Code . DS-AAM-10603**

## **Hot Wire Anemometer with Calibration**

### **Description**

---

#### **Hot Wire Anemometer with Calibration**

##### **Description:-**

This Hot Wire Anemometer measures both temperature and air velocity with two miniature glass-bead thermistors for greater precision—even at low air speeds. Air speed can be displayed in five different units of measure: ft/min, m/s, km/hr, mph, and knots. Switch between °F and °C at the flip of a switch. No moving parts means friction errors are eliminated—ideal for cleanrooms and environmental tests. Recall Min/Max temperatures and velocities, or freeze the display with the HOLD feature.

- Eliminate friction errors caused by vane anemometers
- Connect to a PC to monitor and store readings
- Get accurate, reliable measurements with included NIST-traceable calibration
- Obtain measurements from hard-to-reach places—probe extends to 3 feet (0.9 m).

---

Didac Scientific Pvt. Ltd,  
Martinfield Business Centre, 108 Martinfield, Welwyn Garden City , United Kingdom  
Direct Contact Details ✉ [sales@didacscientific.co.uk](mailto:sales@didacscientific.co.uk)  
🌐 [www.didacscientific.co.uk/](http://www.didacscientific.co.uk/)