

Product Code . DS-AAM-10612

## Multi-Function Ventilation Meters



### Description

---

#### Multi-Function Ventilation Meters

##### Description:-

The Portable, Handheld, Multi-Function Ventilation Test instruments — available with or without a differential pressure sensor — is designed to work with a wide range of plug-in probes. They are designed to measure air velocity, temperature, humidity, CO and CO<sub>2</sub>. Probes feature a smart plug-in connection that stores all the calibration data, so a new probe can be ordered at any time without the need of recalibrating the meter. The probes allow you to make various measurements by simply plugging in a different probe that has the features and functions best suited for a particular application.

- Displays up to 5 measurements simultaneously
- Manual or continuous data logging
- Log up to 26,500 samples and 100 test IDs
- Bluetooth printer capability
- Comes with NIST-traceable calibration report supplied by manufacturer.

