



Product Code . DS-AAM-10631

CFM Vane Anemometer, 4" Vane for Large Areas

Description

CFM Vane Anemometer, 4" Vane for Large Areas

Description:-

This Compact, easy-to-use vane anemometer provides both velocity (flow) and volume flow (cfm). A fixed, 100 mm vane takes flow measurements of large areas like vents, returns, registers, filters, and exhausts. Flow direction, such as inlet suction or exhaust pressure, is shown on the display. This anemometer features both "timed mean" (mean value calculated over a user-specified time) and "multipoint mean" to help track variable flows and cyclical events. Volume flow measurements are simple — just enter the duct dimensions, either circular or rectangular, and the meter automatically calculates the volume flow (cfm) for you. Min. and max. values are displayed, plus a Hold function lets you freeze the display for data recording and documentation.

Didac Scientific Pvt. Ltd,
Martinfield Business Centre, 108 Martinfield, Welwyn Garden City , United Kingdom
Direct Contact Details ✉ sales@didacscientific.co.uk
🌐 www.didacscientific.co.uk/