



Product Code . DS-AAM-10657

Pressure Transmitter

Description

Pressure Transmitter

Description:-

This Versatile Meter, along with the interchangeable transducers, provides a great solution for pressure measurement requirements in HVAC/R, industrial, and process applications. The 2 GB SD card stores data in Excel format for logging and downloading onto your computer for record keeping. The transducers connect to the meter via a 4-pin M12 electronic connection with a 3-ft (0.9-m) long cable.

- Settable parameters of date, time, auto power off, beep sound, sampling time, decimal point or comma decimal division
- Minimum and maximum recallable readings
- Data logging sampling time settable from 1 second to 9 hours.

Didac Scientific Pvt. Ltd,
Martinfield Business Centre, 108 Martinfield, Welwyn Garden City , United Kingdom
Direct Contact Details ✉ sales@didacscientific.co.uk
💻 www.didacscientific.co.uk/