



**Product Code . DS-AAM-10661**

## **Ruggedized Well-Type Manometers**

### **Description**

---

#### **Ruggedized Well-Type Manometers**

##### **Description:-**

Well-Type Manometers provide fast, direct readings of pressure, vacuum, differential, flow and liquid levels. No adding of distances above and below a zero line. All scales are graduated to correct for the drop in well level and are full width of the instrument.

- Ranges: 6, 12, 20, 30, 40, and 60 inches
- Table- or wall-mount style
- Scale has a white, nonglare background with black graduations and figures
- Unit scale extends the full width of the instrument body and is graduated on each side of the indicating column.

---

Didac Scientific Pvt. Ltd,  
Martinfield Business Centre, 108 Martinfield, Welwyn Garden City , United Kingdom  
Direct Contact Details ✉ [sales@didacscientific.co.uk](mailto:sales@didacscientific.co.uk)  
💻 [www.didacscientific.co.uk/](http://www.didacscientific.co.uk/)