



Product Code . DS-AAM-10668

Heavy-Duty Digital Manifold and Pressure Gauge

Description

Heavy-Duty Digital Manifold and Pressure Gauge

Description:-

This Heavy-Duty Manometer measures suction line or liquid line pressure and temperature to calculate and display superheat and sub-cooling for air conditioning (A/C) units. Multifunction differential pressure and temperature meter features Min/Max/Average functions, data hold, and auto power-off. Dual pressure connections, dual temperature connections, and triple-line display—lets you read P1-P2, T1-T2, and ambient temperature measurements simultaneously. The dual Type K thermocouple inputs come with electronic offset to compensate for differences between thermocouple probes—increasing temperature accuracy.

- Accepts two type K thermocouple probes with standard ANSI connections
- 1/4" NPT(M) threaded ports make adaptation easy
- Choose from five pressure units—psi, bar, kPa, in. Hg, and cm Hg.

Didac Scientific Pvt. Ltd,
Martinfield Business Centre, 108 Martinfield, Welwyn Garden City , United Kingdom
Direct Contact Details ✉ sales@didacscientific.co.uk
🌐 www.didacscientific.co.uk/