



Product Code . DS-HP-10694

Compact Thermohygrometer

Description

Compact Thermohygrometer

Description:-

Compact design is ideal for field applications, displays relative humidity or temperature on large LCD. Features data hold, °F/°C selectable reading and analog output signal (10mV/1% RH or 1degF/degC) for use with a chart recorder. Meter utilizes a thin film capacitance sensor for humidity and a semiconductor sensor for temperature measurements. Fast response time of less than 3 seconds, with a sampling rate of 2.5 times per second.

Didac Scientific Pvt. Ltd,
Martinfield Business Centre, 108 Martinfield, Welwyn Garden City , United Kingdom
Direct Contact Details ✉ sales@didacscientific.co.uk
💻 www.didacscientific.co.uk/