



Product Code . DS-HP-10704

Humidity-Temperature Meter with SD Card Data Logging

Description

Humidity-Temperature Meter with SD Card Data Logging

Description:-

This Thermohygrometer records data onto a standard SD memory card, instead of a built-in memory. The data is provided in Excel, allowing the user to easily analyze information without the need for additional software. The advantage of the data being stored on an SD card is when the memory is full the SD card can be simply exchanged out for unlimited data storage. The Thermohygrometer has automatic temperature compensation for dew point, wet-bulb and thermocouple measurements. Meter accepts an optional type-K thermocouple for measuring surface temperature. User settable parameters include; date, time, sampling time, temperature unit of measure, comma or period decimal division and auto power off.

- Easily transfer data using an SD card from your meter to a PC
- Four-function instrument measures humidity, dew point, wet-bulb and temperature
- Large backlit LCD
- Maximum and minimum readings can be recalled or stored for later use
- Adjustable datalogging sampling time settable from one second to one hour.

