



Product Code . DS-HP-10707

Environmental Thermohygrometer

Description

Environmental Thermohygrometer

Description:-

Versatile Handheld Thermohygrometer/psychrometer measures relative humidity, temperature (air/Type K), dew point, and wet bulb temperature. The meter has the capability to measure up to 2372°F (1300°C) with other probes. Store and recall high and low readings using the Max/Min function. Temperatures up to 480°F (250°C) can be measured with the included general-purpose Type K bead wire temperature probe. Freeze and unfreeze readings on the display with the data Hold function. Ideal for residential and professional settings.

- Combines the functions of a humidity meter, type K thermometer, and psychrometer in one compact meter
- Backlit LCD makes viewing in dimly lit areas easy
- Auto power-off with disable option save battery life
- Record maximum and minimum values over time.

Didac Scientific Pvt. Ltd,
Martinfield Business Centre, 108 Martinfield, Welwyn Garden City , United Kingdom
Direct Contact Details ✉ sales@didacscientific.co.uk
🌐 www.didacscientific.co.uk/