



Product Code . DS-HP-10712

Heavy-Duty Thermohygrometer with Infrared Thermometer

Description

Heavy-Duty Thermohygrometer with Infrared Thermometer

Description:-

Meter has a heavy duty rugged double molded housing ideal for use in harsh applications. Built-in infrared thermometer provides non-contact temperature measurement with a 30:1 ratio. Accepts all type K min-connection probes for direct contact temperature readings. View measurements in low light areas with large triple digit backlit display. Meters feature switchable °F/°C units, MIN/MAX that will recall the highest and lowest readings, HOLD button, auto shutoff, low battery indicator and USB interface with Windows compatible software. Combines the functions of a humidity meter, type K thermometer, and infrared gun in to one meter. 2% Relative Humidity accuracy.

Didac Scientific Pvt. Ltd,
Martinfield Business Centre, 108 Martinfield, Welwyn Garden City , United Kingdom
Direct Contact Details ✉ sales@didacscientific.co.uk
💻 www.didacscientific.co.uk/