



Product Code . DS-HP-10720

Dual-Range Light Meter

Description

Dual-Range Light Meter

Description:-

This Dual-Unit visible Light Meter measures from 0 to 50,000 lux or 0 to 5000 foot-candles. Color-correction filter and precise photodiode produce accurate cosine- and color-corrected measurements over the wide range. The photovoltaic cell and microprocessor provide an impressive 0.4 second sampling rate and automatic-zero adjustment. Connect the analog output to a recorder to capture readings, 0.1 millivolt per digit (200 mV max), or display current values on the large 1/2"H digital display.

- Switch between lux and foot-candles; display reading changes color
- Easily read cosine- and color-corrected measurements on the 1/2" LCD.

Didac Scientific Pvt. Ltd,
Martinfield Business Centre, 108 Martinfield, Welwyn Garden City , United Kingdom
Direct Contact Details ✉ sales@didacscientific.co.uk
🌐 www.didacscientific.co.uk/