



Product Code . DS-MM-10732

Digital Pin-Type Paper Moisture Meter

Description

Digital Pin-Type Paper Moisture Meter

Description:-

The moisture scale range for paper is 4.3 to 18%, for baled paper the range is 5 to 40%, and for the reference scale it is 0 to 100. The contact pins mounted on top of the meter provide 5/16" (0.8 cm) penetration for testing paper tubes or corrugated stock. This Electrical resistance type Moisture Meter offers three separate scales: paper, baled scrap paper and reference. The meter also features an audible out-of-range alarm, internal calibration check, 100 data point memory, and average/maximum readings.

Didac Scientific Pvt. Ltd,
Martinfield Business Centre, 108 Martinfield, Welwyn Garden City , United Kingdom
Direct Contact Details ✉ sales@didacscientific.co.uk
🌐 www.didacscientific.co.uk/