

Product Code . DS-LE-10808

## Soldering Iron



### Description

---

#### DESCRIPTION :-

**Power:** min 60W

**Heater:** Nichrome heater

**Length:** 230mm

Stand for nichrome heater type iron

**Stand width:** 74mm,stand

**Depth:**109mm

**Stand height:**129mm

**Stand weight:** 350g

Ceramic bit

#### How to solder : -

When the temperature is high enough, put the solder wire close to the joint, the solder will melt and flow freely.

---



Please remove the solder wire when the tin is enough.

Take away the soldering iron in a direction 45° and power off.

**Power Rating** : 60W

Provided with stand and standard accessories

---

Didac Scientific Pvt. Ltd,  
Martinfield Business Centre, 108 Martinfield, Welwyn Garden City , United Kingdom  
Direct Contact Details  [sales@didacscientific.co.uk](mailto:sales@didacscientific.co.uk)  
 [www.didacscientific.co.uk/](http://www.didacscientific.co.uk/)