

Product Code . DS-LE-10818

Hand Grinder



Description

DESCRIPTION :-

Small diameter barrel grip for added comfort.

Labyrinth construction seals and protects the motor and bearings from dust and debris for longer tool life.

Refined design for reduced operator fatigue.

Protective zigzag varnish seals the armature from dust and debris for longer tool life.

All-ball bearing design and metal gear housing for added durability.

Machined bevel gears provide up to 2x longer service life than previous models.

Spiral bevel gears for smoother rotations and a more efficient transfer of energy.

Side handle is positioned at an increased 20 deg angle for added comfort and control.

Connectable to Makita vacuum cleaner with optional dust collecting wheel guard.

Ideal for welders, fabricators, masons, maintenance/repair and more.

Push button spindle lock for operator convenience.



Power : 720W

Voltage: 220V

Frequency: 50Hz

No Load Speed :11000rpm

Cutting Disk Diameter: 115mm.

Didac Scientific Pvt. Ltd,
Martinfield Business Centre, 108 Martinfield, Welwyn Garden City , United Kingdom
Direct Contact Details  sales@didacscientific.co.uk
 www.didacscientific.co.uk/