

**Product Code . DS-LE-10833**

## Micro-Meter Screw Gauge in Mm



### Description

---

#### DESCRIPTION :-

**Measuring Range** : 0-25 mm (Min)

A Micrometer sometimes known as a Micrometer Screw Gauge, is a device incorporating a calibrated screw widely used for accurate measurement of components in mechanical engineering and machining as well as most mechanical trades, along with other metrological instruments such as dial, vernier, and digital calipers.

Made of nickel-plated brass with ratchet top.

Accurately machined stainless steel rod with range 0-25 x 0.01mm.

Lock tyoe.

For outside measurements up to 25mm.

Supplied in plastic case.

**Precision:** 1/100mm.

---

Didac Scientific Pvt. Ltd,  
Martinfield Business Centre, 108 Martinfield, Welwyn Garden City , United Kingdom  
Direct Contact Details ✉ [sales@didacscientific.co.uk](mailto:sales@didacscientific.co.uk)  
💻 [www.didacscientific.co.uk/](http://www.didacscientific.co.uk/)