



Product Code . DS-P-11115

Screw Gauge

Description

Catalogue No. : "IDAC6525/1.11"

DESCRIPTION :-

- A Micrometer sometimes known as a Micrometer Screw Gauge, is a device incorporating a calibrated screw widely used for accurate measurement of components in mechanical engineering and machining as well as most mechanical trades, along with other metrological instruments such as dial, vernier, and digital calipers.
- Made of nickel-plated brass with ratchet top.
- Accurately machined stainless-steel rod with range 0-25 x 0.01mm.
- Lock type.
- For outside measurements up to 25mm.
- Supplied in plastic case.
- Precision: 1/100mm

Didac Scientific Pvt. Ltd,
Martinfield Business Centre, 108 Martinfield, Welwyn Garden City , United Kingdom
Direct Contact Details ✉ sales@didacscientific.co.uk
💻 www.didacscientific.co.uk/