



Product Code . DS-EE-11459

Insulation Tester

Description

Features :-

- Bargraph to display insulation resistance.
- Displays the value of external AC voltage along with flashing symbol.
- Auto null function to automatically subtract the test lead resistance before displaying the real continuity resistance value.
- Trac-Lok mode to conserve battery life on insulation and continuity tests.
- Live circuit warning beeper.
- Releasing the test button automatically discharges the charges stored in the circuit under test.
- Backlight function to view the test results in dimly lit areas.

Technical Data :

- **Insulation Measurement Range:** 0.2M Ω ~ 1000M Ω
- **Accuracy:** $\pm (5\% + 5d)$
- **Voltage:** 1000 Volt.

• **Accessories:** Test lead, Instruction manual

Didac Scientific Pvt. Ltd,
Martinfield Business Centre, 108 Martinfield, Welwyn Garden City , United Kingdom
Direct Contact Details  sales@didacscientific.co.uk
 www.didacscientific.co.uk/