



**Product Code . DS-EE-11530**

## **Inside Micro meter**

### **Description**

---

**Catalogue No. : “IDAC155/020”**

#### **DESCRIPTION :-**

- Inside Micrometer is a designed to precisely measure things such as the inner diameter of holes.
- The internal micrometer does not have a frame similar to the outside micrometer
- Its anvil is radically ground and hardened. Inside micrometer is meant for measuring diameters of holes and size of the slots.
- It is also used for setting calipers.
- Every Micrometer is intended to make very precise measurements, but the micrometers themselves can be also small or quite large.
- Each inside micrometer will have together a minimum and maximum diameter it is able to measure, so it's common to get inside micrometer sets.
- Measuring range: 5-50 mm.
- Setting ring: 5mm (included).
- Accuracy: 7?m.
- Graduation: 0.01mm.

---

Didac Scientific Pvt. Ltd,  
Martinfield Business Centre, 108 Martinfield, Welwyn Garden City , United Kingdom  
Direct Contact Details ✉ [sales@didacscientific.co.uk](mailto:sales@didacscientific.co.uk)  
💻 [www.didacscientific.co.uk/](http://www.didacscientific.co.uk/)