



Product Code . DS-LE-11737

Sanding Machine

Description

Catalogue No. : “IDAC222/0154”

DESCRIPTION :-

Voltage : 220-240 V

Frequency : 50/60 Hz

Power Input : 350 W

Speed : 4000 - 10000 RPM

Size of Pad : 150 mm

Noise Level : 71 dB

Direct electric random orbital sander developed for effective and dust-free sanding of all kind of surfaces.

With the lowest vibration values in its class and the unique symmetrical design guarantees that the tool can be used for long periods without fatigue.

Direct electric random orbital sander is equipped with a 150 mm (6”) pad and has a 2.5 mm oscillation.